



Sofa Sleep System
Air Over Coil Technology

Patent Pending

Inflating and Deflating Instructions

Your Air Dream™ comes equipped with a U.L. approved electric inflation pump. This pump plugs into a standard 110v household outlet. Position your sleep sofa so that accessing an electrical outlet is convenient.



To inflate mattress:

1. Remove valve cap by simply turning cap counter clockwise.
2. After Cap is removed insert pump motor and turn clockwise until pump is engaged. Allow pump to inflate for 25 - 35 seconds. Remove pump and replace valve cap. (A motor pitch change occurs when mattress is full).
3. Replace valve cap after inflation and seal valve by turning clockwise.



To deflate mattress:

Completely deflate.

1. Open deflation valve by lifting valve latch
(Allow mattress to deflate before folding mechanism.)
2. Swing valve to closed position (do not lock) air trapped in mattress by locking valve could cause damage. Do not lock valve while mattress is folded

**DO NOT CLOSE DEFLATION VALVE
WHEN CLOSING THE SLEEPER MECHANISM.**